



②

* FOR BORED LATCHES, STRIKE AND LATCH CENTERLINES ARE THE SAME. USE 7901 OR 7931 STRIKE MODELS

* 7/8 DIMENSION IS THE ONLY VARIANCE FROM ANSI

NOTE: WHEN DOOR SILENCERS ARE USED ON FRAME, ADJUST STRIKE LOCATION TO ENSURE COMMON LATCH AND STRIKE CENTERLINE.

ADAMS RITE MANUFACTURING COMPANY
POMONA, CA. 91767

7900 ELECTRIC STRIKE
METAL JAMB PREPARATION

PART NO.: 7900T

ECN NO.: 9629

TEMPLATE NO.: 50160-2

DATE: 06-25-97